



Model # IDF750 Frost Fighter

Start Up Instructions

- 1) Connect supply and return fuel lines to fuel supply
- 2) Connect the electrical power supply. Refer to the heater rating plate for the required voltage.
- 3) Turn on the fuel and electrical supplies. Set the heater selector switch to manual or thermostat and the heater should start.
- 4) The heater will purge for 45 seconds before trial for ignition. If the heater does not start check for proper electrical and fuel supplies. Reset the burner control.

Shut Down Procedure

- 1) Turn the heater selector switch to off. The supply fan will continue to run to cool down the heat exchanger.
- 2) To prevent damage to the heat exchanger do not disconnect the power supply until the supply fan stops.